
TCS300B06 說明書

工作電源: DC 24V±10%

指撥開關



1~6 Pin 設定位址 Address: 01H~3FH 7 Pin 設定Frame ON: N82 OFF: N81 8 Pin 設定 傳輸速率Baudrate: OFF→9600

ON → 19200


Modbus Protocol Register Address:

Address	Code	Word	Function	Range
0000Н	03H	1	Channel 1 Data Number	0000H ~ 0FFFH
0001H	03H	1	Channel 2 Data Number	0000H ~ 0FFFH
0002H	03H	1	Channel 3 Data Number	0000H ~ 0FFFH
0003H	03H	1	Channel 4 Data Number	0000H ~ 0FFFH
0004H	03H	1	Channel 5 Data Number	0000H ~ 0FFFH
0005H	03H	1	Channel 6 Data Number	0000H ~ 0FFFH
0006H	03H	1	Channel 7 Data Number	0000H ~ 0FFFH
0007H	03H	1	Channel 8 Data Number	0000H ~ 0FFFH


1~6 channel: AC 0~300V or AC 0~5A 輸入

7~8 channel: DC 4~20mA 輸入

CN 1:



CN 2:



CN 3:

